

DECORATIVE doors & panels / Care & Maintenance

Decorative doors & panels are manufactured from the highest quality materials and designed to provide years of trouble free service.

Whilst your doors are made from a Moisture Resistant Medium Density Fibreboard (MR MDF) and as with any wood based panel cannot be made totally waterproof, care should be taken to wipe up spills immediately, ensuring the doors are not exposed to high or continuous levels of moisture, steam and humidity.

GENERAL CLEANING

Step 1

Wipe down using a damp soft cloth containing warm soapy water, followed by drying using a soft or microfibre cloth so as not to leave any residue on the door or panel. If this is sufficient there is no need for any further action.

Step 2

For more stubborn stains, use a good quality streak free glass cleaner as per the manufacturers recommendation. You may also use Methylated Spirit on a soft cloth, using a circular cleaning motion being careful not to rub too hard.

Step 3

Repeat step 1 - Wipe down using a damp soft cloth containing warm soapy water, followed by drying using a soft or microfibre cloth so as not to leave any residue on the door or panel.

Always ensure that you refer to the recommendations provided by the cleaning product manufacturer before use.

To ensure that your **polytec** warranty will not be void, DO NOT use any of the following on **polytec** Decorative doors & panels: Commercial Cleaning Products, Abrasive Cleaners, Scouring Pads or Abrasive Papers, Acids and Alkalis, Solvents, Thinners, Turpentine (Turps), Ammonia, Bleach, Acetone, Easy-Off BAM!, M.E.K. or any other cleaning agents containing organic solvents or the above mentioned products.

Avoid contact with sharp implements. Use range hoods whenever cooking, to avoid steam and cooking oil vapours from adversely affecting surfaces.

Please note: **polytec** provide a limited seven (7) year warranty on all door products which ensures against design, workmanship and manufacturing defects. If you detect any problems with your doors, **polytec** must be notified within seven (7) years from the date your doors were manufactured. Failure to follow the above care instructions may result in damage to your doors and void your entitlement to the warranty. **polytec**'s warranty does not cover wear and tear.

For more information refer to the **polytec** Products Limited Warranty Terms & Conditions document.

The protective film on your doors, panels and benchtops must be removed within three months of installation.



Scan or click the QR code for the latest Care & Maintenance guides or visit:
www.polytec.com.au/technical/#care-and-maintenance

CONTACT

For further information contact:

Australian Panels Pty. Ltd. (ABN 31 003 246 357)

Address 2 Wella Way,
Somersby NSW 2250,
Australia

Telephone 1300 300 547