

PARTITIONING SYSTEMS

Floor Mounted

Installation Guide

Requirements

A 'check' measure must be completed before ordering systems to ensure correct, accurate installation.

Pre-conditioning of **polytec** Partitioning Systems is recommended. Expose the product to their final environment for as many days as possible before installation, as changes in relative humidity can mean dimensional changes in the panels. The recommended minimum period is five days.

Processing

polytec Partitioning Systems are supplied with panels and components accurately cut and almost completely pre-drilled. In the event further processing is required, **polytec's** Partitioning Systems can be cut, drilled and machined using standard woodworking tools. Cut edges can be lightly sanded. In order to maintain the black core of the Partitioning Systems, an oil such as linseed oil will protect and enhance the edges.

Installation

Installation instructions are included with each **polytec** Partitioning System supplied.

Ensure all windows are positioned in between cubicles and make sure they do not interfere with any wall fixings. The door should be able to swing freely.

Partitions should line up with floor and wall tiles, along with avoiding obstruction to light fittings and air conditioning ducts. Measure partitions accurately to ensure they fall within these points, while also checking walls for plumbing, and floor level.

Fixing

polytec Partitioning Systems are supplied with all hardware and extrusions (excluding screws required to anchor Partition to walls, floor or ceiling).

Correct pilot holes are essential to avoid splitting. They should be 2mm longer than the screw used and should be approximately 90% of the screw core diameter.

Care should be taken not to pre-drill holes through to the other side of the panel, particularly with 13mm Compact laminate.

When drilling the pilot hole, please limit pressure on the drillbit as excessive pressure can cause the far side of the panel to push out.

Storage & Handling

Storage area should be an enclosed space, protected from moisture and heat, away from direct sunlight. When moving product, ensure care is taken to avoid scratching of the decorative surface. Ensure the pooling of water on the surface cannot occur and allow sufficient ventilation and drainage in enclosed spaces.

All packs should be evenly supported at each end, at intervals of no more than 600mm wide. All supports should be vertically aligned where packs are stacked. Minimise leaning panels against walls vertically to avoid bowing.

Care & Maintenance

To maintain the antibacterial effectiveness of **polytec's** Partitioning Systems, the surface should be kept clean. Provided that good hygiene practices are followed; the antibacterial certified surface will be sustained for the expected life of the product. It is recommended after general cleaning; the Compact laminate surface should be wiped down with isopropanol.

polytec's Compact laminate has been independently tested in accordance with industrial standard JISZ2801 test for antibacterial activity and efficacy.

Always ensure that you refer to the recommendations provided by the cleaning product manufacturer before use.

polytec

www.polytec.com.au

p 1300 300 547


STEP 1

- a. Before you begin, review the installation plans and take note of the floor run, window, bulkheads or other objects that may interfere with the installation process.


Leveling blocks are supplied to help aid the installer. Place the blocks on the floor in position of the divisional panels and pack so they are level with the highest point on the floor.

- b. Ensure wall channels are set into position according to measurements, channels are set level and plumb.

- c. Screw the division and end nib channel to the rear and side walls. **Please note:** polytec do not supply the screws.


**STEP 2**

- a. Begin placing the divisional panels into the rear wall channels on leveling blocks.
- b. Do not screw the divisional channels in completely, as adjustments may be needed later to line up the doors and front panels.


**STEP 3**

- a. Determine the floor anchor positions for each nib and frontal, mark the hole positions on the bracket and floor and anchor the floor bracket into position.

Please be aware that the compact panels will sit on the floor bracket, with the back of the bracket being hard against the back of the compact panel.


**STEP 4**

- a. Plumb and fix the end nib into the side wall channel.
- b. As per plan, fit wall channel to frontal.
- c. Fit the frontal nib to the divisional partitions and fix.
- d. Cutting the head rail to desired length, place this into position over the nib and frontals. At this stage, only screw head rail to nib.
- e. Place the infill cap between first frontal and end nib.
- f. Pushing frontal hard against the insert, secure headrail to frontal. Be sure to allow two screws per frontal and repeat for remaining partitions.
- g. Secure floor brackets to nibs and frontal. Be sure to allow two screws per bracket and repeat for remaining partitions.



STEP 5

- a. Fix the hinges and hang doors. Using three screws, secure all divisional panels to the rear channel. Adjust the spring pressure in the bottom hinge until the door operates as desired.
- b. Install the indicator locks, bumpers, hook & handles.
- c. Fix plate to floor once the leg position has been located. Leg can be removed via grub screw on side of base.
- d. Re-fit leg to base and fix to the partition.



NOTE: Do not over tighten door lock screws as excessive force can damage the mechanism and prevent locks from functioning properly. The safest method is to hand tighten screws on all door locks, do not use a drill.